- 1. Spread the arms evenly, check to see that each arm is aligned with the center rod.
- 2.Attached the cap on the round plate then screw the tube to the coupler.
- 3. Screw the loop on the tube.
- 4. Attached the glass on the socket and put the metal washer on the socket then secure by socket ring.

