

## Assembly Instruction For 21313

Put the glass on the socket , then secured by the socket ring .

